

Lista de canales PMR446

CH	frecuencia Mhz	CTCSS	CH	frecuencia Mhz	CTCSS
1	446.00625	no	17	446.00625	114.8
2	446.01875	no	18	446.01875	114.8
3	446.03125	no	19	446.03125	114.8
4	446.04375	no	20	446.04375	114.8
5	446.05625	no	21	446.05625	114.8
6	446.06875	no	22	446.06875	114.8
7	446.08125	no	23	446.08125	114.8
8	446.09375	no	24	446.09375	114.8
9	446.10625	no	25	446.10625	114.8
10	446.11875	no	26	446.11875	114.8
11	446.13125	no	27	446.13125	114.8
12	446.14375	no	28	446.14375	114.8
13	446.15625	no	29	446.15625	114.8
14	446.16875	no	30	446.16875	114.8
15	446.18125	no	31	446.18125	114.8
16	446.19375	no	32	446.19375	114.8

